



Compact HEPA Air Purifier
Model No. AP1C

User's Manual



Questions or Concerns?

contact@enther.com

Thank you for purchasing Enther compact HEPA air purifier.
Should you have any questions or concerns regarding your new product, feel free to reach out to us at

contact@enther.com

We hope you enjoy your new product!

TABLE OF CONTENTS

1. PACKAGE CONTENTS.....	3
2. SPECIFICATIONS.....	3
3. SAFETY INFORMATION.....	3
4. GETTING TO KNOW YOUR AIR PURIFIER.....	6
5. GETTING STARTED.....	9
6. OPERATION.....	9
6.1 General Operation.....	9
6.2 Button Controls.....	10
7. AROMA THERAPY FUNCTION.....	11
8. KEEPING THINGS CLEAN.....	12
8.1 General Maintenance.....	12
8.2 When Should I Replace the Air Filters ?.....	12
8.3 Replacing the Air Filters.....	12
9. TROUBLESHOOTING.....	13
10. CUSTOMER SUPPORT.....	14
11. WARRANTY INFORMATION.....	15

1. PACKAGE CONTENTS

- 1 × Compact HEPA Air Purifier
- 1 × APF1C Activated Carbon & HEPA Filter Set (Pre-installed)
- 2 × Aroma Box
- 1 × User Manual

2. SPECIFICATIONS

Power Supply: AC100-240V~ 50/60Hz

Rated Power: 24W

CADR Rated: 120m³/h

Effective Range: 376.74 ft² (35 m²)

Noise Level: ≤ 58dB

3. SAFETY INFORMATION

Only use this air purifier as described in this manual.


- Ensure the plug properly fits into a polarized power outlet.
- When it's not in use, turn the air purifier off and disconnect it from its power source by removing the plug from the electrical outlet.
- DO NOT operate the unit if cord or plug is damaged. Doing so may result in injury or damage to the unit.
- DO NOT handle the unit with wet hands. Thoroughly dry your hands before handling any part of the air purifier.
- DO NOT immerse air purifier in water or liquids. Doing so may result in damage to the appliance, electric shock, or fire.
- DO NOT use the air purifier in wet or humid environments.
- DO NOT use the air purifier outdoors. This appliance is designed for indoor use only.
- DO NOT use the purifier in a room with major indoor temperature changes as this may cause condensation to build up inside the appliance.
- DO NOT use the air purifier in an enclosed space where

- flammable, combustible or explosive gases are present.
- DO NOT use in an area where toxic vapors, flammable dust or oxygen tanks are present.
 - It is important to keep all objects away from air intake grill.
 - DO NOT insert fingers or objects into air outlet.
 - Child supervision is required while the air purifier is on. Do not allow children to play on or near the air purifier.
 - CAUTION: This unit does not remove carbon monoxide (CO) or radon (Rn). It cannot be used as a device to prevent or clean up accidents with combustion processes and hazardous chemicals.
 - Always make sure to place the air purifier on a flat, surface before operation.
 - Always allow 15 inches (38 cm) of clearance on all sides of the purifier. • WARNING: To reduce the risk of fire or electric shock, do not use the unit with any solid-state speed control device.
 - Place the air purifier so that the power cord easily reaches a standard electrical outlet for a polarized plug.
 - DO NOT run the power cord under carpet. Do not cover cord with throw rugs, runners or similar coverings. DO NOT ROUTE CORD UNDER FURNITURE OR APPLIANCES. Place the power cord away from hightraffic areas.
 - DO NOT use an extension cord with this unit.
 - Never place the unit on soft surfaces such as a bed or sofa.
 - This air purifier should not be used as a substitute for kitchen, bathroom ventilation or vacuum cleaning.
 - DO NOT place anything on top of the purifier
 - DO NOT place the purifier directly below an air conditioner to prevent any moisture from getting into the purifier.
 - DO NOT place the air purifier near sources of heat, such as stove tops, ovens, radiators or computers.


- DO NOT place open flames, including candles, directly in front of the air purifier.
 - DO NOT use this unit with indoor smoke-type insect repellents or in places with oily residues, burning incense, or chemical fumes.
 - This unit should only be used in rooms with temperatures between 14°F and 104°F.
 - Always unplug the purifier from power supply before turning it on. **IMPORTANT:** Please read and comply with all of the instructions and warnings in this manual before using the product. Failure to comply with the instructions and warnings may result in inaccurate results and/or damage to the product itself.
 - This unit should be frequently inspected. Dirt should be removed regularly to prevent excessive accumulation that may result in flashover or fire.
 - DO NOT clean the unit with water or any other liquid to avoid electric shock and/or electrical fires.
 - Only use Enther APF1C replacement filters for this unit. Do not attempt to use other filters.
 - If you experience any problems while operating the air purifier, please refer to the Troubleshooting section on page 12. If you are still having problems with your air purifier, contact Customer Support on page 13.
 - If the unit is damaged or is not functioning well, immediately discontinue use and contact Customer Support.
 - DO NOT attempt to repair this device in any way or use any replacement components or parts to modify the air purifier. Doing so will void your warranty. Contact Customer Support immediately if your unit is no longer working.
- SAVE THESE INSTRUCTIONS!**

4. GETTING TO KNOW YOUR AIR PURIFIER

Top



Bottom





True HEPA & Activated
Carbon Filters Set



Air Outlet


Light Band /
Air Quality Indicator

Outer Layer


Air Inlet

Base

Control Panel



Side



5. GETTING STARTED

1. Take out the aroma box.
2. Flip over the purifier to reveal filter cover.
3. Twist the filter cover counterclockwise to remove the cover.
4. Remove the filters from plastic packaging, then reinstall the filters.
5. Replace filter cover on the air purifier, twist filter cover clockwise to secure filter cover is locked.
6. Replace the aroma box.
7. Place the air purifier on a flat, stable surface with control panel facing up.

6. OPERATION

6.1 General Operation

1. Plug the air purifier into a powered electrical outlet. The unit will chime to indicate that it is connected to a power source.
2. Tap POWER button to turn on the air purifier. After turning on, it will take about 30s running in high speed to detect the air quality, then start producing fresh air on fan speed level I.
3. (Optional): Tap FAN SPEED button to change fan speed of the air purifier. Tap TURBO to set the fan on ultra-high speed to quickly remove dust in the air.
4. (Optional): Tap SLEEP/LIGHT button to set the air purifier to lowest fan speed and dim or turn off the light band.
5. Tap TIMER button to set a timer to turn off your air purifier after 1,4 or 8 hours.
6. Tap POWER button to turn off the air purifier once you stop using the air purifier.

NOTE: It may seem that the airflow is restricted at certain portions of the air purifier when it is operating. This is normal.

6.2 Button Controls

POWER Tap once to turn on or turn off the air purifier.

TIMER Tap TIMER button to cycle through four timer setting: 1H, 4H, 8H, off.

FAN SPEED Tap FAN SPEED button to cycle through 3 fan speeds of the air purifier.

TURBO The fan will run in ultra-high speed to quickly remove dust in the air.

SLEEP / LIGHT Tap once to turn on Sleep Mode, which is the lowest speed setting and the light band will dim.

Tap again to turn off the light band.

Tap once again to turn off sleep mode, the light band will light up and the air purifier will turn back to the latest fan speed setting.

NOTE:

- Sleep Mode is the lowest fan speed.
- You can also tap FAN SPEED or AUTO button to opt out of Sleep Mode.

AUTO Turns on or turns off automatic sensor inside the air purifier. This mode will automatically adjust fan speed according to the air quality to provide clean air for your living space.

You can also tap FAN SPEED to opt out of Auto Mode.

LIGHT BAND / AIR QUALITY INDICATOR

The table below shows different colors of air quality indicator in correlation to both air quality & fan speed.

Color	Air Quality	Fan Speed
Red	Bad	High
Orange	Moderate	Medium
Blue	Good	Low

You can also use it as a night light.

7. AROMA THERAPY FUNCTION

The built-in aroma therapy unit allows you to add any liquid aroma that you want. The tailor-made wood fiber particles in the aroma box help to lock-in the aroma, release aroma slower and keep aroma longer. Remove aroma lid to access aroma box.

Maintenance

Aroma Box

1. Add aroma therapy about once a month
 - Add or change aroma when aroma effect has decreased.
 - Do not add different aroma scents in the same spice box.
2. Add Aroma Oil
 - Open the cover and then take the aroma box out. Take care to keep the aroma box flat.
 - Drop essential liquid spice into the middle round entrance.
 - Do not add over 2ml (6-8 drops) liquid spice into the spice box.
 - Invert the spice box after 10 minutes' standing and make sure no oil evacuates before reinstalling the aroma box.
 - Do not put the aroma box into the air purifier when it stained with residual aroma oils.



External Surface

Please use dry, soft fabric to wipe the surface, inlets and outlets.

- Do not use any chemical cleaning agents.

8. KEEPING THINGS CLEAN

8.1 General Maintenance

- Wipe down outer layer with a soft, clean cloth.
- DO NOT immerse the purifier in water or liquid detergents.
- If necessary, wipe outer layer with a clean damp cloth, then immediately dry outer layer with a separate clean cloth.

8.2 When Should I Replace Air Filters?

It is recommended to change air filters every 6 months. However, you may need to change your filters sooner or later depending on how often you use your air purifier.

It is important to watch out for the following signs of expired filters:

- Increased operating noise
- Decreased airflow
- Clogged filters
- Increased presence of odors

NOTE:

- The environment in which the air purifier being used may also extend or shorten the lifetime of air filters. Using your air purifier in an environment of relatively high pollution may need to change the air filters more frequently.

8.3 Replacing Air Filters

1. Turn off and unplug the air purifier.
2. Take out the aroma box, flip over the purifier and remove the filter cover.
3. Remove old filters.
4. (Optional) Clean any remaining dust or hair inside the purifier using a vacuum hose. DO NOT use water or liquids to clean the purifier.
5. Only use Enther APF1C replacement filter, remove new filter from packaging and place it into the purifier

6. Replace filter cover onto outer layer. Turn filter cover clockwise to the lock position.
7. Replace the aroma box.

9. TROUBLESHOOTING

Problem	Cause	Solution
Air purifier makes an unusual noise while operating.	Air filters are dirty.	Replace the air filters as instructed in the Replacing the Air Filters section.
	Filter does not fit properly.	Properly place filter(s) as noted in the Getting Started and Replacing the Air Filters sections.
	Foreign object inside the unit.	Immediately discontinue use and contact Customer Support. DO NOT attempt to open the air purifier.
Significantly reduced airflow.	Filter packaging has not been removed.	Remove filter from packaging before use.
	Fan speed is low.	Press FAN SPEED to adjust fan speed.
	Air filters need to be replaced.	Replace the air filters as instructed in the Replacing the Air Filters section.
	Not enough clearance on all sides of the purifier.	Ensure there is at least 15 inches (38 cm) of clearance on all sides of the purifier.
Poor air purification quality.	Air filters need to be replaced.	Replace the air filters as instructed in the Replacing the Air Filters section.
	Room is too large for the air purifier's applicable area.	Ensure the room is smaller than 376.74 ft ² (35 m ²) .
	Air inlet or outlet is blocked.	Remove objects blocking air inlet or outlet.
	Filters are not properly placed in outer layer.	Properly place filters as noted in the Getting Started and Replacing the Air Filters sections.

10. CUSROMER SUPPORT

Should you encounter any issue or have any questions regarding your new product, feel free to contact via Amazon Buyer-Seller Messages or Email.

Email: support@enther.com or warranty@ucieapp.com

11. WARRANTY

Entner warrants all products to be the highest quality of material, craftsmanship, and service for a minimum of 1 year, effective from the date of purchase. Warranty may vary between product categories. For specific warranty terms, please refer to your product's listing page or operation manual.

Additional 1-Year Warranty

Ucie Protection goes above and beyond the manufacturer's warranty to extend your coverage and protect your purchase, offering parts even full replacement of covered products from day one.

Sign up for Ucie Protection now to get 1-year bonus warranty and drone accessories by logging onto <http://warranty.ucieapp.com>

For fast mobile convenience, scan this QR code to the registration page for quicker warranty extension.



Contact warranty@ucieapp.com for more information about Ucie Protection.